### Instructions of Safety and Warnings:

- · Any failure to comply with the safety and installation instructions in this manual may cause serious bodily injury.
- Overlooking any part of the instructions, warnings and additional information marked with the "Note" and "\n" may result in serious damage to the system or its components.
- Children should never be allowed to operate or touch the product without direct supervision of an adult. Users should prevent children from being near or around the desk during operation.
- Disabilities and/or lack of experience and knowledge should be prevented from using the product unless under supervision or assisted during use and operation.
- · Never sit on or exceed the rated weight of the desk

## **Electrical Safety Instructions:**

The product is powered by electricity. In order to avoid burns, fire and electric shock, please read the

Don't clean the product with water while the power is still connected.

Don't disassemble or replace components while the power is still connected.

Never operate the system with a damaged cord or plug. Please contact your point of purchase to replace the damaged parts.

Never operate the system if it's in moist environment or its electrical components have contact with liquids.

Don't operate the system if the control box makes noise or odor. Alterations of the given power unit and control box aren't allowed.

### **Other Safety Instructions:**

- ${f \cdot}$  Remove any obstacles from the area around the desk during assembly and subsequent use.
- $\bullet$  Organize all cords and wires to prevent any possible tripping or accidents from occurring.
- Never attempt to modify or change the desk frame or components that operate the desk.
- Don't add anything to the adjustable junctions of the desk frame.
- · The desk is rated for Indoor Use Only.

6. Drilling to the Desktop



**Disposal:** The product with this mark indicates that this product shouldn't be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the local recycle service or contact your point of purchase to withdrawn the product.





# GetUpDesk Duo

Instruction Manual

ET2650SI/ET2650WH/ET2650BL










#### **■** Checklist and Installation

Please check all of the components shown in the component checklist. If any of the components are missing or damaged, contact your point of purchase for a replacement.











Controller

Adapter Holder










AC Adapter











#### 2. Attaching the Side Brackets

- Attach each Side Bracket to the Lifting Column using 2 M6x10 Screws S-A.
  Attach 6 Anti-Vibration Pads S-G to the crossbars and Side Bracket as shown below.
  Repeat the same process to attach the other side bracket.




#### 3. Attaching the AC Adapter

ullet Insert the AC Adapter ullet to the Adapter Holder ullet , then hang the holder on the crossbar.



#### 4. Attaching the Feet

- Attaching the Foot 🕞 to the Lifting Column using 4 M6x35 Screws S-C
- · Repeat the same process to attach the other foot



#### 5. Adjusting the Frame and Attaching the Crossbar Rail

- Carefully place the desktop (not included) upside down on the blanket/floor.
- Carefully place the desktop (not included) upside down on the blankeyhoor.
  Place the legs one on each side of the top as shown below.
  Adjust the crossbar to the size of the desktop. Ensure that the frame is placed in the center of the desktop.
  Attach the Crossbar Rails as shown below.
  Secure the frame using 4 M6X12 Screws S-B.
  Tighten the screws on the crossbar.

