


### Headrest adjustment:

To adjust the headrest height, lift up the headrest (①) to desired position.

To adjust the headrest angle, turn the headrest directly to desired angle.

### Lumbar Supporter adjustment:

To adjust the lumbar supporter height, hold the lumbar supporter (②) and move up or down to desired position.




### Armrest adjustment (③):

To adjust the armrest angle, press the button under the top and rotate the armrest to desired position, armrest rotating can be 360 degree.

To rise up or lower down the armrest, press the button on the armrest and move up or down.

To move the arm top position, push the top forward or pull backward.

To adjust the arm width, push down the lever to unlock the arm, pull out or push in the arm to desired position, then pull up the lever to lock.



### Seat depth adjustment:

To enlarge the seat depth, pull out the slider lever (④) and move forward to desired position, then release the lever.

To go back to the first position, pull out the slider lever again and remove body weight from the seat.

### Seat height adjustment:

To raise the seat height, remove weight from the seat and pull up on the height adjustment lever (⑤), release the lever when reaching the desired position.

To lower the seat height, while seated, pull up slowly on the height adjustment lever until the seat is at the desired height.

### Tilt tension adjustment:

To adjust the seat tilt tension, turn the tension adjustment knob (⑥) on the mechanism to desired tension, turn clockwise or anticlockwise. Clockwise to stronger and anticlockwise to weaker.

### Backrest angle adjustment (Tilt/Swing Lock):

To change backrest's position, pull up the adjustment lever

(⑦), then lie backwards the backrest to desired position, and push down the adjustment lever to lock.

To go back to the first position, pull up the adjustment lever, lie backwards again and then backrest will return automatically.

Part	Picture	Qty.
A		5
B		1
C		1
D		1
E		1
F		3
G		1
H		2
I		2
J		1
K		2
L		1
M		2

